BHOME

ASSEMBLY INSTRUCTION

MODEL :SLIP LEAF CHAIR

Read this instruction carefully. See hardware and furniture part list for guidance Be sure all parts are complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched.

CAUTION

- 1. Do not fully-tighten the JCBC bolt until all parts are ready assembled.
- 2. Do not over-tighten the JCBC bolt to avoid causing damages to the thread.

HARDWARE LIST				
ITEM	DESCRIPTION		QTY	
А	JCBC SCREW M6 x 40MM	 ()	2 PCS	
В	JCBC SCREW M6 x 50MM	. ()	4 PCS	
С	JCBC SCREW M6 x 80MM	 0	4 PCS	
D	SPRING WASHER M6 x 12 x 2.0MM	0	10 PCS	
Е	FLAT WASHER M6	0	10 PCS	
F	CSK SCREW M4 x 32MM	- +	10 PCS	
G	ALLEN KEY M4		1 PC	

PARTS LIST			
ITEM	DESCRIPTION	QTY	
1	BACK REST	1 PC	
2	BOX SEAT	1 PC	
3	CUSHION SEAT	1 PC	
4	FRONT LEG(L)	1 PC	
5	FRONT LEG(R)	1 PC	
6	STRECTHER(L)	1 PC	
7	STRECTHER(R)	1 PC	

