
Components


A 2×Seat Cushion



B 1×Left Back Cushion


© 1×Right Back Cushion





2 STR

Simple Assembly Instructions-Please keep for future reference



- Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
- 4. Ensure you have enough space to lay out all the parts before assembly.
- 2. Check that you have all the component 5. To avoid scratching it is recommended parts and familiarise yourself with that you assemble the unit on a soft each part before proceeding.
- 3. Take all the fittings out of the plastic bag and separate them into groups.

Stage1-Fitting the Unit

NOTE: It would be useful to asl someone to help you at this

Insert the Back Rest onto the Seat Cushion.

Engage the Metal Locks and push fit. You should hear them lock into NOTE: Carefully align the two sid align correctly. Metal Locks. Ensure they


Fit the Velcro cover on the Back Rest onto the Velcro on the back of Seat Cushion.

See fig. 1

DO NOT ALLOW CHILDREN TO PLAY ON THIS MECHANIZED FURNITURE OR OPERATE THE MECHANISM.

LARGEST FOLDS DOWN ON CLOSING SO THAT A CHILD COULE NOT POSSIBLY BE INJURED. ALWAYS LEAVE IN AN UPRIGHT AND CLOSEN POSITION. KEEP HANDS AND FEET CLEAR OF MECHANISM. ONLY OCCUPANT SHOULD

CAUTION:



Stage2-Fitting the Unit

Back and Foot Rest Adjustment

the features to be sitting in the chair to activate rest and raised foot rest. You need This Chair features a reclining back

1. Pull the "Adjustment Lever" and gently lean back and the chair will automatically lift up. recline and the foot rest will

See fig. 2

 \bigcirc

W

2. Pull the "Adjustment Lever" again and lean forward, the back rest will lower. will move forward and the foot rest

See fig. 2


3. Adjust the recliner to your own requirements.

NOTE: It would be useful ask stage. someone to help you at this

4. Finally carefully place the unit in the desired location

Velcro





Care and Maintenance

Safety

0040

OBO

Metal

Lock

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning

As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive

Fitting

Fig. 1

From time to time please ensure there are no loose screws on the product.