

ASSEMBLY INSTRUCTIONS



ITEM #: C8183A-045-7DXX&C8183A-050-MBXX

DRESSER&MIRROR

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staple used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. please do not over tighten screws or bolts until the assembly is complete.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

STEP1



PART LISTS

NO.	DESCRIPTION	SKETCH	Q'TY
(1)	DRESSER		1PC
(2)	MIRROR		1PC
(3)	MIRROR SUPPORTS		2PCS
(4)	BUN FEET		4PCS
(6)	CENTER SUPPORT LEG WITH LEVELER		2PCS
(7)	JEWELRY BOX		1PC
(8)	DIVIDER		1PC

PART LISTS

NO.	DESCRIPTION	SKETCH	Q'TY
A	BOLT		1/4"*45mm 8PCS
B	SPRING WASHER		1/4"*13mm 8PCS
C	FLAT WASHER		1/4"*19mm 8PCS
D	ALLEN KEY		4mm 1PC
E	TIPPING RESTRAINT		1SET