

KD BACK ASSEMBLY AND REMOVAL

1. REMOVE COVER FROM KD “ARM” ON EACH SIDE OF THE RECLINER.
2. LINE UP ARMS ON BOTTOM OF RECLINER WITH BRACKETS ON THE BACK OF THE RECLINER.
3. SLIDE ARM INSIDE BRACKET AND PUSH DOWN. YOU SHOULD HEAR A CLICK. THIS MEANS THE BACK IS LOCKED IN PLACE.

TO REMOVE BACK: USING A SCREWDRIVER, LIFT THE CLIPS ON THE BRACKET TO UNLOCK THE BACK. LIFT STRAIGHT UP ON THE BACK OF THE RECLINER.



KD BACK ASSEMBLY AND REMOVAL WITH POWER HEADREST

1. REMOVE COVER FROM KD “ARM” ON EACH SIDE OF THE RECLINER.
2. LINE UP ARMS ON BOTTOM OF RECLINER WITH BRACKETS ON THE BACK OF THE RECLINER.
3. SLIDE ARM INSIDE BRACKET AND PUSH DOWN. YOU SHOULD HEAR A CLICK. THIS MEANS THE BACK IS LOCKED IN PLACE.
4. PLUG THE MOTOR INTO THE HEADREST.



TO REMOVE BACK: UNPLUG THE HEADREST FROM THE MOTOR. USING A SCREWDRIVER, LIFT THE CLIPS ON THE BRACKET TO UNLOCK THE BACK. LIFT STRAIGHT UP ON THE BACK OF THE RECLINER.