

Stage1 –Fitting the Unit

NOTE: It would be useful to ask someone to help you at this stage.

1. Carefully align connecting hooks & holes into position and lock them to secure the mechanism.
See Fig. 1
2. Insert the Left Back Cushion® Middle Back Cushion® and right Back cushion® onto the unit.
3. Locate the Velcro on the flap of the Back Cushions onto the back of Seat Cushions.

CAUTION :

DO NOT ALLOW CHILDREN TO PLAY ON THIS MECHANIZED FURNITURE OR OPERATE THE MECHANISM. LARGEST FOLDS DOWN ON CLOSING SO THAT A CHILD COULD NOT POSSIBLY BE INJURED. ALWAYS LEAVE IN AN UPRIGHT AND CLOSED POSITION. KEEP HANDS AND FEET CLEAR OF MECHANISM. ONLY OCCUPANT SHOULD OPERATE IT.





Fig. 1

Stage2–Fitting the Unit

Back and Foot Rest Adjustment

This Chair features a reclining back rest and raised foot rest. You need to be sitting in the chair to activate the features.

1. Pull the "AdjustmentLever" and gently lean back and the chair will recline and the foot rest will automatically lift up.

See fig. 3

2. Pull the "AdjustmentLever" again and lean forward, the back rest will move forward and the foot rest will lower.

See fig. 3

3. Adjust the recliner to your own requirements.

NOTE: It would be useful ask someone to help you at this stage.

4. Finally carefully place the unit in the desired location.

See fig. 4




Fig. 3




Fig. 4

Care and Maintenance


Safety To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Fitting From time to time please ensure there are no loose screws on the product.


WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.



IMPORTANT

1. Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
2. Check that you have all the component recommended parts and familiarize yourself with unit on a soft each part before proceeding.
3. Take all the fittings out of the plastic bag and separate them into groups.
4. Ensure you have enough space to lay out all the parts before assembly.
5. To avoid scratching it is recommended that you assemble the level surface.



Finished

⚠ WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to wall. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.