


ATTENTION:

Before you sit and enjoy your new chair, please remember to install the anti-tip supports on the underside of the metal mechanism.




The supports will be found in the red hardware pack attached to the drive tube of the mechanism. Please follow the steps listed in the assembly instructions for proper attachment.


After installation, please go ahead and take a seat and relax. Thank you for your purchase!

Lift Recliner Assembly Instructions

- Your recliner comes packaged in one box.
- **DO NOT** use any sharp objects to open plastic wrapped components as damage to product or components may result.
- Carefully remove all of the components from the packaging and set aside for assembly.
- Assemble on a soft surface to prevent scratching the finish.
- Zip ties are used to secure Your recliner cords and avoid damage - **DO NOT** cut.



Parts List



A 1 x Seat

B 1 x Back

Hardware List



C 2 x Legs



M1/4"*40mm

D 4 x Bolts



M1/4"


E 4 x Wing nuts




* Replaceable Parts
Hardware bag can be found
under the seat

Assembly


Step 1




Step 2




Step 3




Step 4




Remote Use




Hold the Up button to lift chair /
bring the recline position upright



Hold the Down button to recline /
bring lift position down




Proper Usage



- Steps to safely stand up from your Lift Recliner
1. Store remote safely in the recliner's side pocket
 2. Plant feet firmly on the ground
 3. Evenly distribute weight on both arms of the chair
 4. Slowly stand up from lift position

*Remember to store remote safely
in the recliner's side pocket
when it is not in use



*Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.

Improper Usage



DO NOT stand up when
the footrest is in the
upright position



DO NOT stand up from
your recliner with
uneven weight



DO NOT stand up from
your Lift Recliner with
one arm

Your recliner style may differ from images

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.