










SYMMETRY 3HPFP

Assemble Instruction & Parts Identification


- step1; Turn sofa over on a clean and flat surface and open the parcel
- step2; Install the legs to the chair bottom
- step3; Turn the chair to its upright position

	①	②	③	④	⑤	⑥	⑦
	Steel wahser	Hexagon wrench	Scerw	Rear Leg	Front Leg (longer)	Rear plastic Leg (longer)	Front plastic Leg
Spare parts							
	4	4	1	2	2	2	4






1. Slide the metal receiver over the metal post. Press both sides of back firmly downward until locked in place.



3. Locate the transformer P and connect

2. Locate the power cord C attached to the bottom back and connect to plug D located at the rear of seat.



Note:
Make sure all **PLUGS** are connected on the product before plugging power cord into power outlet. If not damage can occur.
The USB ports (where applicable) are designed with working voltage of 5V, and can NOT be used to supply power for laptop computers (neither PC or Mac). Plugging a laptop computer to the USB port may end up damaging either the computer or the USB port due to unmatched working voltage.