

ASSEMBLY INSTRUCTIONS

MODEL :0268A
EASTERN KING (5+6+8)

(Box 1)
BOX OF HEADBOARD & FOOTBOARD

No	ITEM	Qty
A	Headboard	1 pc
B	Footboard	1 pc
C	Headboard Leg (L/R)	2 pcs


(Box 2)
BOX OF SIDE RAIL

No	ITEM	Qty
D	Side Rail	2 pcs
E	Slat With Stopper	2 pcs
F	Slat W/o Stopper	3 pcs
G	Slat Support	8 pcs
H	Concealed Panel	6 pcs


(Box 1)
HARDWARE LIST

No	ITEM	Qty
1	ALLEN KEY m4x65mm Bk	1 pc
2	JCBC M6 x 30mm	6 pcs
3	SPRING WASHER 1/4" Row	6 pcs
4	Flat Washer 1/4"/ID x 13mm/OD Bk	6 pcs

STEP 1 : Attach Head Board Leg (C) to Head Board (A) as shown using JCBC BOLT (2) with Spring Washer (3), Flat washer (4) and securing with ALLEN KEY (1).



STEP 2 : Hook SIDE RAIL (D) TO HEAD BOARD (A) closely and push down to fit. repeat step 2 with other end of rail to hook onto FOOTBOARD (B).




STEP 3 : Tighten the 4 Corner with Allen Key (9). Fix the Bed Slat Support Leg (G), to Bed Slat (E) & (F) using JCBC (6) as shown. Install the bed slat to side rail (D) and tighten with Csk Screw (5) as per diagram shown. (NOTE: THE SETUP MUST BE DONE AT THE DECIDED LOCATION FOR THE BED TO OBTAIN PERFECT STABILITY)

(Box 2)
HARDWARE LIST


No	ITEM	Qty
5	Csk M4 x 32mm	10 pcs
6	JCBC M6 x 50mm	8 pcs
7	Pan Head Chipboard Screw m3.5x20mm	30 pcs
8	ALLEN KEY m4x65mm Bk	1 pc
9	ALLEN KEY m5x65mm Bk	1 pc

STEP 3.1 :


Push the side rail (D) meet with wooden slat (E) & (F) by follow the marking line provided and fix the Csk screw (5) by using the Screw Driver.




STEP 3.2 :



STEP 3.3 :




STEP 3.4 :




NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.

ASSEMBLY INSTRUCTIONS

STEP 4 : Attention! Screw on this markings on concealed panel slat (H).



STEP 4 : Attach Concealed Panel (H) over the Bed Slat (E)&(F) using Panhead Screw (7) and tighten with Screw Driver. (Not included)



NOTE : MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.